

## Front Window Removal Tool Operation

The Blu-Vue Front Window Ring is used to hold the window against an O-ring to prevent water from entering the camera housing from the front. There are four dimples in the front window ring that allow the ring to be hand tightened to seal the front of the camera. The Front Ring Removal Tool is used to place the ring initially as well as to remove the ring for repair or calibration.

